

Washplanes Made From Corian®

Installation Guide for Washplane 3211L-900



1. Please check the washplane is in perfect condition before proceeding to installation.
2. Please ensure all fixing brackets and screws/bolts are in the box.
3. Ensure the structure / wall is sound and load bearing to take the weight of the unit. This washplane weights approximately 32KG.
4. All required wall support fittings have been included with your product together with screws and plugs.
M6*60 screws for hanging brackets.
M8*80 expansion bolt for direct fixing.
Please ensure that you use a sharp masonry bit to drill the holes. The M8*80 bolt need drill $\phi 10\text{mm}$ holes.
5. Once the hanging supporting male brackets are securely fixed, slide the unit down onto the pre-installed unit fitting. Be sure all fixtures are seated into the fixings. And then fix the M8*80 expansion bolt.
6. If required, please make sure that you use a good quality silicone to seal where the back of the washplane meets the wall.

